

MAGICSEAL PRO SHEET INSTRUCTIONS

Premium Reusable Finishing Sheet for DTF, DTG, White Toner Transfers, HTV/Vinyl & More

1



COMPLETE YOUR NORMAL TRANSFER

Press and peel your transfer normally according to the instructions for the transfer film, technology or fabric you are using.

2



COVER THE FINISHED DESIGN

Place the MagicSeal PRO Sheet over the finished image with the textured side facing down against the print.

3



FINAL PRESS AT YOUR NORMAL TEMPERATURE

Press using the same temperature as your first press.

- More temperature resistant than the regular MagicSeal Sheet
- Operating range: 270–330°F / 132–166°C

4



COLD PEEL — WAIT 10–15 SECONDS

After pressing, leave the PRO Sheet on the garment for 10–15 seconds before removing.

- Allows the print to settle into the fibers
- Helps prevent color migration onto the sheet
- Especially important with HTV/Vinyl and other heat-sensitive applications

5



WASHABLE & REUSABLE

The PRO Sheet may attract dust or debris. Wash gently with water and allow it to dry completely before reuse.

6



LONGER LASTING / WHEN TO REPLACE

- Lasts approximately 500–1,000 presses
- Replace after 1,000 maximum presses
- Even if still visually intact, the proprietary silicone coating wears over time which reduces performance



MAGICSEAL SHEET VS. MAGICSEAL PRO SHEET

FEATURE	MAGICSEAL SHEET	MAGICSEAL PRO SHEET
Color	○ White	● Black
Temperature Range	270–290°F / 132–143°C	270–330°F / 132–166°C
Washable	✗ No	✓ Yes
Expected Life	Approx. 300–500 presses	Approx. 500–1,000 presses
Peel After Press	Standard use	Cold peel – wait 10–15 sec



Do not cut either sheet.



Use for final post-press only.



Always follow proper heat press safety procedures.



HTV/Vinyl is especially sensitive to hot removal. Always cold peel for best results.